



HALO DESK LIGHT

USER INSTRUCTION

300 SPECTRUM CENTER DRIVE, STE 400 | IRVINE CA 92618
OFFICE 949 754 4040 | FAX 949-627-2757
INFO@MOCHASOLUTIONS.COM | MOCHALIGHTING.COM

POWER ON

Press the On/Off button once



OCCUPANCY SENSOR AND TIMER USAGE (optional when ordered)

The HALO desk lamp is specified and designed to save energy while providing the most amount of light at lowest power consumption. With work day timer, the light will stay on for 10hrs. With occupancy sensor, the light will stay on 20 min and shut off, but will continue turn back on immediately after detecting motion by the sensor.

Arm can swivel 360 degree at the base, while the head unit can rotate vertically for desired light placement.

INSTALLATION PROCEDURE FOR PLUG-IN UNIT

Carefully plan out your installation prior to actually securing your HALO desk lamp to the desk surface making sure that your 6 ft. line cord will reach the nearest electrical outlet.

TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT
POUR EVITER LES CHOCS ELECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA
FICHE DANS LA FENTE LA PLUS LARGE

1. Consult a local licensed electrician or electrical contractor if you are not sure about the installation
2. DO NOT ATTEMPT TO INSTALL THE FIXTURE WHILE PLUGGED IN.
3. Select a suitable dry mounting location (for indoors only). Make sure mounting surface is completely capable of supporting the fixture.
4. For base mount, unwrap the base on the surface. Insert the light body onto the post of the base fully.
For clamp mount, install by rotating knob clockwise to tighten clamp to edge of table. Insert the light body onto the post of the mount fully.
For panel mount, secure the mount fully onto panel. Insert the light body onto the post of mount fully.

DIMMING

HOLD the On/Off button to achieve the desired intensity. HALO desk lamp provides continuous dimming from low (5%) to high (100%) and high (100%) to low (5%).

5. Plug in power adapter plug to the connector tightly at the HALO lamp

6. Plug fixture into a 120VAC 60Hz outlet.

For warranty info, go to
mochalighting.com/warranty

CLEANING INSTRUCTIONS

Your fixture is made from quality materials that will last many years with minimal care. When cleaning, make sure you have unplugged your fixture and have allowed sufficient time for the unit to cool to room temperature. You should clean the housing and lens using a damp soft cloth. You should plug your fixture back in only after the fixture has thoroughly dried.

DISPOSAL

Follow local disposal laws. See
WWW.LAMPRECYCLE.ORG